

**Work Order ID 104437****\*104437\***

Page 1

Item ID: D206-642-113

Accept

**\*N900040100\***Setup Start **\*NS1\***

Revision ID:

Stop **\*NS2\***

Item Name: Skidtube LH, Low Gear Run on Landing

Start Date: 7/11/13 Start Qty: 1.00

**\*1\***

Cust Item ID:


Required Date: 7/12/13 Req'd Qty: 1.00

**\*1\***

Customer:

Reference:

Approvals:

Process Plan: 

Date: \_\_\_\_\_

Tooling: \_\_\_\_\_

Date: \_\_\_\_\_

Run Start **\*NR1\***

QC: \_\_\_\_\_

Date: \_\_\_\_\_

SPC (Y/N): \_\_\_\_\_

Date: \_\_\_\_\_

Stop **\*NR2\***

Sequence ID/ Work Center ID	Operation Description	Set Up/ Run Hours	Tool ID	Tool #	Plan Code	Accept Qty	Reject Qty	Reject Number	Insp. Stamp
--------------------------------	--------------------------	----------------------	---------	--------	--------------	---------------	---------------	------------------	----------------

Draw Nbr

Revision Nbr

IIN-D206-642

O

100

0.00

**\*100\***

DOCUMENT CONTROL

DC

Memo

0.00

Document Control

Photocopy bluefile & type labels per PPP206-642-113 CHG003  
K10111 CHG003

110

0.00

**\*110\***

Pick Kit

Packaging

Memo

0.00

Packaging

120

0.00

**\*120\***

QC4- 100% Inspect kits for completeness

QC

Memo

0.00

Quality Control

SU

DAS 31 8-9

13-9-19

12/9/19

DAS 06 8-13

DAS 31 8-9

13-9-19

# Work Order ID 104437

\*104437\*

Page 2

July-11-13 7:45:30 AM

Item ID: D206-642-113 Accept: \*N900040100\* Setup Start \*NS1\*  
 Revision ID: Stop \*NS2\*  
 Item Name: Skidtube LH, Low Gear Run on Landing  
 Start Date: 7/11/13 Start Qty: 1.00 \*1\* Cust Item ID:  
 Required Date: 7/12/13 Req'd Qty: 1.00 \*1\* Customer:  
 Reference:

Approvals: Process Plan: \_\_\_\_\_ Date: \_\_\_\_\_ Tooling: \_\_\_\_\_ Date: \_\_\_\_\_ Run Start \*NR1\*  
 QC: \_\_\_\_\_ Date: \_\_\_\_\_ SPC (Y/N): \_\_\_\_\_ Date: \_\_\_\_\_ Stop \*NR2\*

Sequence ID/ Work Center ID	Operation Description	Set Up/ Run Hours	Tool ID	Tool # Plan Code	Accept Qty	Reject Qty	Reject Number	Insp. Stamp
130	Packaging	0.00						
*130*								
Packaging	Memo	0.00						
Packaging	Identify and pack for shipping as per PPPD206-642-113							
	K10111							
	Location: FG082							
	PPP Rev: _____							
140	QC21- Final Inspection - Work Order Release	0.00						
*140*								
QC	Memo	0.00						
Quality Control								

DAS  
06  
8-8

13-9-19

13-09-20

# Picklist Print

July-11-13 7:45:29 AM

Page 1  
4

Work Order ID: 104437

Parent Item: D206-642-113

Parent Item Name: Skidtube LH, Low Gear Run on Landing

Start Date: 7/11/13

Required Date: 7/12/13

Start Qty: 1.00

Required Qty: 1.00

Comments: IPP REV:A 10.12.08 PER REV:N DD VERF:EC IPP REV:B 11.09.23 ADDED  
K10111 DD VERF:EC IPP REV:C REDESIGN PER ENG ERROR 11-11-17 JLM  
VERIFIED BY:DD IPP Rev:D 12.11.21 ECN12-  
679 DD verf:JLM

Component Item ID/ Item Name	Replacement Item ID	Mfg/ Purch	Bin Item	Primary Location	Last Location	Route Seq ID	Unit of Measure	Qty on Hand	Qty per Kit	Total Qty	Qty Issued	Date Issued	Status
<u>D206-642-151</u> Repl. skidtube low gear (run on landing) LH or RH <i>[Signature]</i>		Manufactured	No			110	Each	1.0000	<i>[Stamp: DAS 06 9-89]</i>	1	104266		
				<u>Location</u>		<u>Loc Qty</u>		<u>Loc Code</u>					
				FG082		1							
				77976		1							
<u>K10111</u> Saddle, Skidtube 206 <i>[Signature]</i>		Manufactured	No			110	Each	2.0000	<i>[Stamp: 1]</i> <i>[Stamp: DAS 06 9-89]</i>	1	95366		
				<u>Location</u>		<u>Loc Qty</u>		<u>Loc Code</u>					
				PKG14		2							
				92501		1							
				95024		1							